

These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

STOW & GO SEAT BRACKET INSTALLATION

Immediately upon delivery, open all packages and check the contents of the shipment. Report any issues directly to SCP within 15 days. After 15 days, SCP will not be responsible for missing or damaged items.

INSTALLATION INSTRUCTIONS

WARNING: SEAT IS SPRING LOADED. BE CAREFUL WHEN PULLING THE LEVER IF NOT ACTUALLY SITTING IN THE SEAT.

1. Remove belt buckle from the seat. This has already been done for you if you purchased the seat(s) from Small Car Performance.

2. Remove old seats.
3. We strongly recommend test fitting the brackets in your van before installing onto the Stow & Go Seats.
4. Remove the plastic sleeve (if present) that rests inside the tracks.
5. Slide seat bracket onto the track. The bracket should go on smoothly, but if not, it will be important to remove any debris and adequately clean. You may even have to pry up or hammer down any metal tabs that may be interfering with the bracket sliding on and off.



6. Remove the brackets and bolt to the Stow & Go seats using the provide bolts. Make sure the set screw holes on the bracket (red arrows) are in the front on the seats.
7. Slide brackets and seats onto the van's tracks. With the passenger seat this can be done with the seat folded or extended. Do whichever is more convenient.
8. The driver seat can only be installed fully extended because of the steering wheel. This will take a bit of maneuvering.
9. Line up bracket's set screws (arrows) to holes on the track and tighten with a 13mm socket or wrench.

