

These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

VANAGON RADIATOR FAN & SHROUD

Immediately upon delivery, open all packages and check the contents of the shipment. Report any issues directly to SCP within 15 days. After 15 days, SCP will not be responsible for missing or damaged items.

INSTALLATION INSTRUCTIONS

1. To avoid any damage to the electrical system, disconnect the battery.
2. Disconnect the wiring from the factory radiator fan. Try to preserve as much length as possible.
3. Disconnect Radiator Thermal Switch and remove lower grill.
4. Remove radiator per the Bentley (Repair Group 19). Keep in mind this can be accomplished without disconnecting coolant pipes or A/C hoses.
 - Remove bottom radiator elbow brackets.
 - If equipped with factory A/C: remove A/C hose bracket on the driver's side of the van to give enough slack to allow the radiator to drop.
5. Attach Fan Shroud to the back of the radiator either reusing factory hardware or the provided #14 x ½" screws.
6. Reattach Radiator and Fan Shroud to the van.

7. Connect the new Radiator Fan to the factory wiring. **Please note: the wiring does not match the traditional VW color code scheme.**

8. Radiator Fan & Shroud Wiring connections:

- *Black wire* connects to the *brown ground wire*.
- *Grey and brown wires* are interchangeable and can be connected to either of the remaining factory wires.



Parts List:

| | |
|-----------------------------------|-------------------------------|
| 3 x Butt Connector Blue 16-14 AWG | 3 x Male Quick Connect Blue |
| 6 x #14 x ½" Screw | 3 x Female Quick Connect Blue |
| | 1 x Shroud & Fan Assembly |